




# LK-CP611 Control Panel

## Terminal



Symbol	Description	Symbol	Description
L	AC live wire	FSO	Fire signal output
N	AC null wire	FOO	Fire output NO
E	AC earth wire	FOC	Fire output NC
24V+	24VDC input positive	24V	24VDC+ output
24V-	24VDC input negative	FSI	Fire signal input
M+	24VDC motor positive	COM	Sensor COM
M-	24VDC motor negative	S+	Slave control up
MU	Manual switch up	S-	Slave control down
MS	Manual switch stop	12V	DC12V+ output
MD	Manual switch down	WRD	Rain sensor down
MG	Manual switch GND	T/H	T/H signal

## Manual control

- After power on all the LEDs light for 1 second and turn off, the power indicator LED normally on
- Press reset button, all the LEDs light for 1 second and turn off, reset successfully
- L2 will be explosion-flashing after controller receives fire signal
- External manual switch is equivalent to controller panel switch
- The maximum running time of the motor is 5 minutes
- Press UP button, the windows open, LED turns on, turns off after 5 seconds
- Press DOWN button, the windows close, LED turns on, turns off after 5 seconds
- Press STOP button, the motors stop, LED turns on, LED turns off after 1 second

## Remote control

- The controller encodes by 433MHz learning code, can store 10 sets of transmission codes

## Matching code

- Power the controller on
- Pressing STOP button on controller for 5 seconds, LED flashes 3 times and turns off
- Press UP within 15 seconds
- LED flashes 3 times and turns off, code matched successfully

## Clearing single code

- Power the controller on
- Keep pressing STOP key on the controller for 5S, LED flashes 3 times and turns off
- Press DOWN button on the remote within 15 seconds
- LED flashes 3 times and turns off, code cleared successfully


## Clearing all codes

- Power controller on, pressing STOP /DOWN button on the controller for 5 seconds
- LEDs flash 3 times and turn off, all the codes will be deleted after this operation

## LK-CP611 Control Panel

### ■ Cascaded control

- Can be used as a master controller, a slave controller or play a dual role of master & slave controller at the same time
- As a master controller, connects to the motors or slave controllers to drive them
- As a slave controller, input terminals S+ and S- are connected to the output terminals M+ and M- of the master controller to receive the instructions to drive motors, or drive the motors independently
- Play a dual role of master & slave controller, not only controlled by higher-level controller, but also drive motors or lower-level controllers independently
- No matter master, slave or both, it can process all the external signals such as manual switch, remote and sensors
- Cascade use of the controller, if the master controller connected to an external sensor (such as smoke sensor, wind and rain sensor, etc.), the slave controller **MUST NOT** use inching mode, in case the master controller received the smoke signal to open the window, the slave controller will open the window for a very short moment and stop



### ■ Signal control

- Manual signal. Control the window by the buttons on itself, external dry contact manual switch and RF remote
- Cascaded signal. As a master controller sends signal to the slave controller, can also be used as slave controller to receive the signal from the master controller to drive the window
- Fire signal. Capable of receiving a signal from fire center, smoke sensor, gas detector open the window automatically, send feedback signal to fire centre
- Rain signal. After receiving the signal of rain sensor close the window
- Temperature/humidity signal. Control the window by processing external temperature/humidity sensor

### □ Signal and priority

Priority	Signal	Device
1	Manual signal	Panel buttons, manual switch, remote, master controller
2	Fire signal	Smoke sensor, gas detector
3	W/R signal	Wired wind rain sensor
4	T/H signal	Temperature sensor, humidity sensor

### □ Reset and shielding

- After manual signal processed controller receives input signal in real time
- After processing the signal from fire centre, smoke sensor or gas detector, the controller immediately shields all the input signals, the controller must be reset by pressing K1 manually
- After wired rain sensor signal processed, the controller shields lower priority signal, only receives the higher priority signal until reset or manual signal processed
- After T&H sensor signal processed, the controller is in the reset state
- If the controller is not connected to a temperature and humidity sensor, the T/H port must be shielded (put option switch to "Y" position)

## LK-CP611 Control Panel

### ■ Control mode

- Controller has inching mode and continued-run mode which is default
- In the continued-run mode, press UP or DOWN button less than 1.5 seconds, the motor will run continuously, press UP or DOWN button more than 1.5 seconds, the motor will stop after running a very short moment
- In the inching mode, press UP or DOWN button less than 1.5 seconds, the motor will stop after running a very short moment, press UP or DOWN button more than 1.5 seconds, the motor will run continuously
- Only the manual buttons on the panel, manual switch, remote control and cascade signal have inching mode
- Keep pressing both of UP and STOP button on the controller for 5 seconds, LEDs flash 3 times and turn off it's inching mode for the controller, repeat the operation the controller turns to continued-run mode

### ■ Stroke memory

- The controller can set and memorize opening stroke. Upon the stroke set, the window opening signal is triggered once, the motor will run the memorized stroke one time
- The default memorized stroke runs for 5 minutes
- Press both of UP/DOWN buttons on the controller for 3 seconds, LEDs flash 3 times and off, successfully entered the stroke memory setting state
- In the stroke memory setting state, the manual keys are forced to the continued-run mode, the remote control keys are forced to the inching mode
- Determine the stroke that needs to be memorized by pressing the manual key or the remote control key by moving or jogging
- Press both of UP/DOWN on the controller for 3 seconds, LEDs flash 5 times and off, the memorized stroke set successfully and exit the stroke memory setting state, manual buttons and remote control buttons restored to the original mode
- No operation is performed within 15 seconds, LEDs flash 3 times and off, the stroke memory setting state is automatically exited, and the last memorized stroke is retained
- Stroke memory can be set repeatedly. The controller only retains the last successful stroke value and automatically clears the previous one
- In stroke memory setting state, press both of STOP /DOWN buttons on the controller for 3 seconds LEDs flash 3 times the memorized stroke is deleted and restored to the default output for 5 minutes
- When the memorized strokes of master controller and slave controller are not the same, the master controller will run its own memorized stroke. The slave controller will run the shorter stroke when it receives the cascade signal from the master controller
- The memorized stroke is retained in case the controller is powered down or reset
- When closing the window, the output time is 5 minutes

### ■ Installation instruction

- Please read the following instructions carefully before installing this product
- Installing this product must comply with the effective local electricity specifications
- The control system must be installed by the professional
- The main power must be cut off before wiring to ensure safe operation
- Maximum output power MUST NOT exceed the rated power of the controller
- Do not use metal objects to touch or cover the controller, otherwise it will affect the remote control signal reception
- The maximum transmission distance of the wireless signal can reach 50 meters or more in the open condition
- The distance between the controller and ground should be more than 1.5 meters
- The distance between the controller and ceiling should be more than 0.3 meters
- The distance between the controller and motor should be more than 1.5 meters
- Avoid static interference and prevent static damage to electronic components
- Please use the soft wire and cable, after installation ensure that the cable carrier is not affected by the longitudinal tension
- An external sensor must use a product that is compatible with this controller
- Non-professionals is not allowed to disassemble the controller. If any function is abnormal, please contact your local dealer

### ■ Troubleshooting

No.	Symptom	Solution
1	LED flashes, receiver shut down	1. Check the connection of wires 2. Check the receiver setting
2	LED on the transmitter is off or weak	1. Make sure the right installation of the battery 2. Change the battery
3	The transmitter and the receiver work well, the motor does not work	1. Check the wiring of motor 2. Make sure the motor no failure